

STAINLESS STEEL ACCESSORIES

DOOR WINDOW SHADE, FLD CAB

INSTALLATION INSTRUCTIONS

1. Remove plastic from mounting flanges (flanges with rectangular holes.)
2. Hold shade up against door and align properly. Ensure that the outside curved profile of the shade conforms to the outer edge of the door.
3. Hold part securely in position and mark the door through the rectangular holes (a hook shaped scriber may be required if access with a pencil is too difficult)
4. Set window shade aside and drill through marked holes with $\text{Ø}1/4''$ drill bit.
5. Fasten with supplied hardware as shown.

